

PROBLEM	SOLUTION
<i>I can't see the Camera on my TV</i>	Ensure the camera and receiver are plugged in. and the TV/VCR/DVR is tuned to the correct input channel as described on page 9.
<i>A white image appears at night</i>	The camera's infra-red LEDs shine invisible light that reflects off surfaces such as glass causing white light. Place the camera on the other side of windows or place the lens flush against the surface to try to improve the night vision or place in a well lit area.
<i>I keep getting interference in my home or business</i>	The wireless camera operates on the 2.4GHz frequency like many devices such as wireless routers, cordless phones, and microwaves. If possible keep the camera(s) and receiver away from these devices.